

! For your safety, follow ALL instructions in the User Manual to minimize the risk of fire, electric shock, exposure to ozone gas, property damage, personal injury, or loss of life.

INITIAL SET-UP


Turn Power On

- 1 Plug the ZONO™ Compact Cabinet into outlet specified in the user manual and turn switch to ON.
 - **Note:** Always keep Power Switch ON to ensure sensors and magnetic locks are activated.



Set-up Humidity System

- 2 Remove packing material around Water Reservoir.



- 3 Add distilled water up to the fill line in the **Water Reservoir**.
 - Using distilled water reduces potential mineral build up which can cause deposits of oxidation inside the ZONO™ Compact Cabinet.
 - If difficult to reach, you may move the water reservoir closer to the front of the cabinet, if the wire can reach. After filling reservoir with distilled water, return it to its holder.
 - Ensure Humidifier Cage is upright, and Water Reservoir is in Holder.




RUN A CYCLE

Run a Cycle

- 1 Load the Bins into the ZONO™ Compact Cabinet.



- 2 Reach Inside and Press the Green Button.



Green button is located inside at the top of the ZONO™, next to the magnetic lock.

- 3 Close Door, Enter Access Code, Press Enter, and Select Start Cycle or Lock Door.



Enter access code: 1364, Enter



Lock Door or Choose cycle to run. Door will beep if not locked in 10 minutes.



NOTICE
Do Not Store Objects on Top of the ZONO™ Cabinet.

The Magic Eraser included with each machine, is to remove fingerprints from surfaces.



Not Using the ZONO™ for a Week or More? As with any appliance that utilizes water, avoid possible mold growth by not storing items in the ZONO™ or leaving standing water for a week or more. Drain the Water Reservoir, wash with soapy water, and air dry thoroughly. Access the water reservoir by lifting the humidity cage up and out, placing it on a paper towel in the machine. Water reservoir can be removed from its holder, emptied, washed with soapy water and air dried. When you are ready to use the ZONO™ after the idle period, add distilled water to the fill line in the reservoir, place humidity cage in the reservoir and place back in the holder at the bottom of the cabinet.